USER MANUAL

# AT-WIND

## Shaft Alignment

acoem

# CONTENT


| | |
|---|---|
| Welcome to our world | 1.1 |
| Declaration of Conformity | 2.1 |
| Safety | 3.1 |
| Care | 4.1 |
| Apps | 5.1 |
| Wind - Shaft Alignment | 6.1 |
| Hot Check | 7.1 |
| Sensors M10 and S10 | 8.1 |
| Sensors M9 and S9 | 9.1 |
| ACOEM Home - Launcher | 10.1 |
| Flir One | 11.1 |
| Technical Specification M10 and S10 | 12.1 |
| Technical Specification M9 and S9 | 13.1 |

# WELCOME TO OUR WORLD

*For 40 years, ACOEM has helped industries throughout the world to achieve more profitable and sustainable production. We have reached where we are today by having the courage to think beyond the norm and follow slightly unconventional paths. We have had the courage to make mistakes and find new directions. Through our resolve, ambition, and knowledge we have become a global player and a leader in innovative, user-friendly reliability solutions.*

## SUSTAINABLE INNOVATIONS

During our 40 years in this industry, we have explored, tweaked, and tested more than anyone. Some might say we are incurable innovators whereas others might say that we are highly focused. They both probably have a point. If we had not been devoted and ambitious, we would not have been the first in the field of laser alignment to have a touch screen. Nor would we have been pioneers in the use of visible lasers and dual measurement heads. Nor would we have been the first to bring a wireless vibration sensor for machine diagnostics. We are now the first to provide a combined alignment and diagnostic solution on standard mobile devices.

Over the years, we have learnt to never compromise on quality, and we are constantly in search of new, unexplored opportunities by combining advanced technology with design and function. By doing so, we have become the leading innovator in our industry. Not only do we minimize wear, production stoppages and costs, but we also help save the environment. Natural resources are in short supply and if we can contribute to a more sustainable world by making it a little bit straighter, we could not be happier.

## TRUE COMMITMENT

One reason for our success is our solid commitment. We have ensured that we remain attentive to constantly picking up on the needs of the market. Our expert employees and dedicated dealers in over 70 countries are undoubtedly our most important asset. Satisfaction and team spirit are of particular importance to us and are consistently at the top of our priority list. With experience from a wide range of industries and manufacturing processes, we are fully aware of the problems and needs of our end-customers. We are passionate about what we do, and we are driven by the desire to eliminate anything in the industry worldwide that may be even slightly out of line.

## PURE USABILITY

Our design and user-friendliness are carefully interwoven. As we develop new products, they also become cleaner, smarter, more functional, and more robust. An industrial environment is demanding, infinitely more difficult to work in and inevitably subject to time pressure. There is no place for equipment with unnecessary functions, complicated interfaces and that is difficult to assemble.

Usability and user friendliness mean everything, not only to us but also to our customers. We have designed products that are easy to learn and can be incorporated quickly. By removing non-essential functions, we make life less difficult for our users – and probably a little more difficult for our competitors.

## END USER LICENSE AGREEMENT

The rights to use the software in this product are offered only on the conditions that you agree to all the terms stated below, i.e., the end user agreement. By using this product, you agree to be bound by this agreement. If you do not accept this agreement your sole remedy is to return the entire unused product, hardware, and software, promptly to your place of purchase for a refund.

The user is granted a single license to use the software contained in this product. Use is only permitted on the hardware it has been installed on at the time of purchase. The software may not be removed from the hardware. The software contained in the system is the property of ACOEM group, any copying or redistribution is strictly prohibited.

Modifying, disassembling, reverse engineering or decompiling the system or any part thereof is strictly prohibited.

Disclaimer of warranties: To the maximum extent permitted by applicable law, ACOEM and its suppliers provide the software contained in this product ‘as is’ and with all faults, and hereby disclaim all other warranties either expressed, implied or statutory.

Limited liability: No liability shall exceed the price of the product, and the sole remedy, if any, to any claim shall be a right of return and refund.

ACOEM or its suppliers shall, to the maximum extent permitted by applicable law, not be liable for any indirect, special, incidental, punitive, and consequential damages arising from the use of the system or any part thereof, authorized, or unauthorized.

ACOEM group is headquartered in Lyon, France. For more information, please visit acoem.com

1.4

# DECLARATION OF CONFORMITY

In accordance with
2014/35/EU Low Voltage Directive
2014/53/EU Radio Equipment Directive
2012/19/EC Waste electrical and electronic equipment (WEEE)
2011/65/EU Restriction of the use of certain hazardous substances (RoHS)
2006/66/EU Battery Directive
2001/95/EC CE marking directive

**Type of equipment**

Alignment Tool

**Brand name or trademark**

ACOEM

**Type designation(s)/Model no(s)**

1-1278 M10
1-1279 S10
1-1263 M9
1-1264 S9

**Manufacturer's name, address, telephone & e-mail address**

ACOEM AB
Box 7
SE-431 21 Mölndal
Sweden

Tel: +46 31 7062800
E-mail: info.se@acoem.com

**Standard/Test report/Technical construction file/Normative document**

The following standards and/or technical specifications, which comply with good engineering practice in safety matters in force within the EEA, have been applied:

EN 61000-6-3:2007.

EN 61000-6-2:2005, EN 61000-4-2, -3, -4, -5, -6, -11.

EN 61010-1:2010

ISO9001:2015 Ref. No/ Issued by: DNV Certification AB Certification No. 2009-SKM-AQ-2704/2009-SKM-AE-1419.

The laser is classified in accordance with the International Standard IEC-60825-1:2014, USA FDA Standard 21 CFR, Ch 1, Part 1040.10 and 1040.11 except for deviations pursuant to laser notice No. 50, dated June 24, 2007.

The wireless device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions;
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

**Additional information**

The product was CE-marked in 2025.

As manufacturer, we declare under our sole responsibility that the equipment follows the provisions of the Directives stated above.

**Date and place of issue**

Mölndal 2025-03-03

**Signature of authorized person**



Peter Strömberg, CTO

# SAFETY

Retain and follow all product safety and operating instructions. Observe all warnings on the product and in the operating instructions.

Failure to observe the safety pre-cautions and operating instructions can cause bodily injury, fire, and damage to the equipment.

Do not disassemble, modify, or use the equipment in other ways than explained in the operating instructions. ACOEM AB will not accept any liability for such use.



**WARNING!**


Do not mount equipment on running machines and take all appropriate measures to prevent unintentional start-up of machines. Make sure to fully comply with all appropriate shut down procedures, safety measures and regulations at worksite and local regulations regarding safety in a machine environment.

## LASER PRECAUTIONS

The system uses laser diodes with a power output of < 1.0 mW. The laser classification is Class 2.

Class 2 is considered safe for its intended use with only minor precautions required. These are:

- Never stare directly into the laser transmitter.
- Never shine the laser directly into anyone else's eyes.






**CAUTION!**

USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

Your system complies with the requirements in:

- IEC-60825-1:2007
- British Standard BS EN 60825-1
- DIN EN 60825-1
- USA FDA Standard 21 CFR, Ch 1, Part 1040.10 and 1040.11

## POWER SUPPLY

The sensors are powered by high-capacity rechargeable Li-Ion batteries mounted in the sensors or by the external power unit.



The sensors can be connected to their charger and charged while lying in the case. It is important that the lid of the case is open during the charging and that the charger is placed outside the case or else the system will not be charged properly and might be damaged.

Do not expose the power adapter to rain or wet conditions.

Always unplug the charger from the electrical outlet after charging.

Leaving a display unit or a measurement unit with an empty battery for a prolonged time can reduce the capacity of the battery or even damage the battery.

If the system is not used for a long time, charge the batteries to approximately 50-75% before storing the system, if kept in storage repeat this every 3-4 month (if needed).

When used in typical conditions the battery will sustain good capacity for approximately 2-3 years before needing replacement. Contact your sales representative for battery replacement.

The batteries contain safety circuitry to operate safely with the display unit. The unit can therefore only be used with the Li-Ion batteries supplied by ACOEM.

Improper replacement of batteries can cause damage and risk for personal injury.



**WARNING!**

BATTERY REPLACEMENT SHALL ONLY BE PERFORMED BY AUTHORIZED ACOEM REPRESENTATIVES.

USE OF ANY OTHER BATTERIES THAN THOSE SUPPLIED BY ACOEM WILL CAUSE SEVERE DAMAGE TO THE SENSOR AND CAN CAUSE RISK FOR PERSONAL INJURY!

Handle any batteries with care. Batteries pose a burn hazard if handled improperly. Do not disassemble and keep away from heat sources. Handle damaged or leaking batteries with extreme care. Please keep in mind that batteries can harm the environment. Dispose of batteries in accordance with local regulatory guidelines, if in doubt contact your local sales representative.

Only use the external power adapters supplied by ACOEM for use with the sensors. Using other power adapters can cause damage to the unit and personal injury.

## WIRELESS TRANSCEIVER

The sensors are fitted with Bluetooth wireless transceivers.

Make sure that there are no restrictions on the use of radio transceivers at the site of operation before using the wireless transceivers.



**WARNING!**


Before using the wireless transceivers make sure that there are no restrictions on the use of radio transceivers at the site. Do not use on aircraft.

# CARE

## CLEANING

The system should be cleaned with a cotton cloth, or a cotton bud moistened with a mild soap solution, except for the detector and laser window surfaces, which should be cleaned with alcohol.

For the best possible function, the laser diode apertures, detector surfaces and connector terminals should be kept free from grease or dirt.




Do not use paper tissue, which can scratch the detector surface.



Do not use acetone.

The chains on the V-brackets are delivered dry. If the system is used in highly corrosive environments, the chains should be oiled.

## DATE OF CALIBRATION DISCREPANCY

Our instruments store the electronic date of the latest calibration of the instrument. Due to production processes and storage time, this date will differ from the date of the calibration certificate. Hence, it is the date of the calibration certificate which is important and that indicates when the next calibration is due.

# APPS




Wind - Shaft Alignment







Download the app from Google Play or App Store.

The Wind - Shaft Alignment app works with the sensors M10 & S10 and M9 & S9.


Available functions depend upon which system you have selected.

5.2


# WIND - SHAFT ALIGNMENT

## INTRODUCTION

Shaft alignment: Determine and adjust the relative position of two machines that are connected so that the rotational centers of the shafts are collinear, when the machines are working in a normal operating condition. Correction of horizontal shaft alignment is done by moving the front and the rear pair of one machine's feet, vertically and horizontally, until the shafts are aligned within the given tolerances. A tolerance table is available in the system.



The system has two measuring units that are placed on each shaft by using the fixtures supplied with the system.




After rotating the shafts into different measuring positions, the system calculates the relative distance between the two shafts in two planes. The distances between the two measuring planes, distance to the coupling and distances to the machine feet are entered into the system. The display box then shows the actual alignment condition together with the position of the feet. Adjustment of the generator can be made directly, according to the displayed values.

The alignment results can be saved for further documentation purposes.

## PRE-ALIGNMENT FUNCTIONS

To obtain the best possible conditions for shaft alignment, it is necessary to perform some pre-alignment checks. In many cases it is necessary to make these checks to obtain precise alignment. It is often impossible to reach the desired alignment results if you do not make any pre-alignment checks.

Before going on site, check the following:

- What are the required tolerances?
- Any offsets for dynamic movements?
- Are there any restrictions for mounting the measuring system?
- Is it possible to rotate the shafts?
- What shim size is needed?

Before setting up the alignment system on the machine, check the machine foundation, bolt, and shim condition. Also check if there are any restrictions in adjusting the machine (if e.g., there is enough space to move the machine).

After the visual checks have been performed, please follow the equipment manufacturers instructions regarding alignment procedures, there are some conditions that typically should be considered:

- Check that the machine has the right temperature for alignment.
- Take away old rusty shims (check that you can remove shims).
- Check coupling assembly and loosen the coupling bolts.
- Check soft foot conditions.
- Mechanical looseness.

- Check coupling and shaft run-out.
- Coarse alignment.
- Check coupling gap (axial alignment).

The Pre-Alignment app can be used for several Pre-Alignment checks.

There is also a Softcheck function in the Wind - Shaft Alignment app.

## STARTING

Turn on the sensors.


Turn on the tablet.

Start the Wind – Shaft Alignment app.

The Wind - Shaft Alignment app works with the sensors M10 & S10 and
M9 & S9.

Some functions work only with the sensors M9 & S9. These functions are marked with a sensor 9 symbol.

Require M9 & S9.



Go to settings for connecting the sensors if they are not already connected.

Settings.

Settings are described at the end of the chapter.

Select an already configured machine in the machine list or a new machine.



Machine list.



New machine.

## MOUNTING


Mount the fixtures and sensors according to the manufacturer's instructions.

The sensor marked "M" should be mounted on the movable machine and the sensor marked "S" on the stationary machine.

### Adjust height M10 & S10

Adjust the height of the sensor by sliding it on the posts until a line of sight is obtained for both lasers. Secure its position by locking both clamping devices on the back of both units.






**Adjust height M9 & S9**


Adjust the height of the sensor by sliding it on the posts until a line of sight is obtained for both lasers. Secure its position with the green knobs.



## MACHINE CONFIGURATION

The screen displays the movable machine.

The traffic lights show green when the laser hits the detector.




The sensor values can be enlarged by touching them.






Touch the distance icon, to enter distances and tolerance.

### Measure and enter distances





You must enter all the distances. The distance between the sensors, the distance between the center of the coupling and the M-sensor, the distance between the M-sensor and the first pair of feet and the distance between the first and the second pairs of feet.

**Enter tolerances**

Alignment tolerances depend mostly on the rotation speed of the shafts. Machine alignment should be carried out within the manufacturer's tolerances.

The provided table can be helpful if no tolerances are specified. It is also possible to enter customized tolerances.

The tolerances are the maximum allowed deviation from desired values.







Select the tolerance to use in the alignment by touching its check box to the left.



Confirm.



Touch the edit icon to enter and edit customized tolerances.




Editing mode for customized tolerances

**Select coupling**


Select coupled or uncoupled coupling in the configuration screen.

Go to the configuration screen.


Select coupling type.

Coupled

Uncoupled




Coupled coupling.



Uncoupled coupling.

## CONFIGURATION SCREEN





**Distances**




Opens window for entering distance.

**Tolerance table**




Opens the tolerance table.

**Target Values**



Opens Target Values.

**Add New Template**



Adds the pre-defined machine to the template list.

**Add New Machine**



Adds the pre-defined machine to the machine list.

**Machine List**



Opens the machine list.

**Restart**



Deletes all entered data and restarts the app.

**Coupling**



Select coupling type.

Coupled or uncoupled coupling.

Coupling gap on/off and Spacer Shaft on/off.

**Motor**



Select motor color.

Grey, blue, green, yellow, or red.

**Hot Check**



Opens Hot Check.

**Confirm**




Confirms the machine configuration.

## MACHINE LIST

The are two tabs in the machine list, one for templates and one for machines.

## TEMPLATES





The template list shows pre-defined templates.

It is possible to order the template list depending on each column's status by touching the column header.

A template is shown with a template symbol, template name and creation date.

Touch a template to expand the view and show more details.




Confirm to measure the selected template.

**Create templates**

Templates can be created in the configuration screen.

**Import template list**

A template list can be imported.


Import a template list

**Export a template list**

A template list can also be exported.

Export a template list

## MACHINES




The machine list shows pre-defined machines and work orders.

Work orders require connection to the ACOEM Augmented Mechanics Platform. (See Settings and Cloud Synchronization at the end of this chapter.)

It is possible to order the machine list depending on each column's status by touching the column header.

For example: To bring all overdue work orders that must be managed urgently to the top of the list, click on the work order column header.

**Pre-defined machines**

Pre-defined machines can be created in the configuration screen.

A pre-defined machine is shown with a machine symbol, machine name and creation date.

Touch a machine to expand the view and show more details.




Confirm to measure the selected machine.

Other options in the expanded view.

PDF report.

Delete the machine.

Upload to cloud.

**Work orders**

A work order is shown with a work order status symbol, machine name and due date.

Touch a work order to expand the view and show more details.




Confirm to measure the selected work order.

Other options in the expanded view.

PDF report.

Delete the work order.

Close the work order.

Upload to cloud.

**Work order status**



Work order to realize, not started.



Work order soon overdue (<1 week).



Work order closed.



Work order overdue.

**Cloud sync status**



Waiting to be synced.



Synced.



Not connected to cloud.


## SOFTCHECK™



Go to Softcheck for checking soft foot conditions.

A soft foot condition needs to be corrected before any alignment takes place. If not, the measurement result will be of no value. It is more or less impossible to establish if there is a soft foot condition without using some kind of measurement tool. The Softcheck application checks each foot and displays the result in mm or mils.

Place the sensors at the 12 o'clock position.




All the distances must be entered, before checking for soft foot.

Check that all foot bolts are firmly tightened.

**Measurement value registration**

The application will guide you to the feet.

The first foot.




1. Loosen the bolt fully and wait a few seconds.
2. Tighten the bolt firmly, preferably with a torque wrench.
3. Register the measurement value.



Touch the confirmation icon.

Repeat the procedure at the rest of the feet.










**Measurement result and Corrections**




Make the necessary corrections and then check each foot again (the values show approximately how many shims that are needed to eliminate the soft foot).

Re-measurements can be done by touching the re-measure icon to re-measure all feet, or by touching a single foot to re-measure just that foot.



Re-measure all feet.



Re-measure a single foot.

The Softcheck result can be saved separately.



Touch the save icon to save the result.

(The measurement is saved in the app and can be handled further by generating a PDF report.)

## TARGET VALUES



Go to Target Values to enter target values.

(Target Values are reached from the configuration screen.)


### Introduction

Most machines develop a certain amount of heat while running. In some cases, both the gear box and the generator are affected equally requiring no input of compensation values. But in many cases the gear box and the generator are affected independently, therefore target values are required.

Machine manufacturers define the thermal expansion of machines differently, but in most cases, you will find it as a factor of deliberate misalignment expressed in parallel offset and angular error.


You can pre-set target values before starting your alignment work. Accepted values are feet values and angle and offset values.

The entered values are target values. Target values mean that these are the values at which the machine should be positioned when not running (cold condition) to obtain correct alignment while the machine is running (hot condition).





Select one of two ways to express the offset values: Feet values or angle and offset values.

**Feet values**





Touch the feet value boxes. Enter target values for the feet in mm or mils according to the pre-set measurement unit together with the required distances.





In the example above, the stationary machine will shrink vertically by 0.12 mm at the rear feet and 0.09 mm at front feet while the movable machine will expand 0.04 mm while running.

Horizontally, the rear feet will move 0.05 mm towards you and the front feet will move 0.03 mm away from you while the movable machine does not change its position while running.






After having entered these feet values, the system calculates how the movable machine should be positioned (target position) in cold condition to obtain perfect alignment during running condition.

**Angle and offset values**





Touch the value boxes and enter target values for the angles in mm/100 mm and target values for the offsets in mm, or mils/inch and mils, according to the pre-set measurement unit.




In the example above, the movable machine should be vertically adjusted to a position with an angular misalignment of +0.05 mm/100 mm and an offset of -0.06 mm.




Horizontally, the movable machine should be positioned with a
+0.02 mm/100 mm angular misalignment and a +0.03 mm offset, in cold condition to obtain perfect alignment while running.

## MEASUREMENT METHODS



### Tripoint™ method

In the Tripoint method, the alignment condition can be calculated by taking three points while rotating the shaft at least 60°.

NOTE: The shafts should be coupled during measurement to achieve as reliable and accurate results as possible, when using the Tripoint method. But it can be used for uncoupled shafts.

TIP: The larger the angle over which the three points are measured, the fewer moves, and repeat measurements will have to be made. The minimum angle between readings is 30°.




### Express Mode™ method

The Express Mode method works as the Tripoint method with the following additions.

The first position can be registered automatically, if the shafts first are rotated counterclockwise more than 3° between 6 o'clock and 12 o'clock and then clockwise more than 3°. The reading is then taken automatically when the sensors have been stationary for 2 seconds.

After recording the 1st point, the other points are taken automatically when the shafts are rotated to a new position and are kept in position for more than 2 seconds.

NOTE: The shafts must be coupled during measurement when using the Express Mode method.



## Multipoint method

In the Multipoint method, the alignment condition can be calculated by recording 6 to 9 points while rotating the shafts at least 50°.

NOTE: The shafts should be coupled during measurement to achieve as reliable and accurate results as possible, when using the Multipoint method. But it can be used for uncoupled shafts.

TIP: The larger the angle over which the three points are measured, the fewer moves, and repeat measurements will have to be made. The minimum angle between readings is 10°.




## Multipoint express method

The Multipoint express method works as the Multipoint method with the following additions.

The first position can be registered automatically, if the shafts first are rotated counterclockwise more than 3° between 6 o'clock and 12 o'clock and then clockwise more than 3°. The reading is then taken automatically when the sensors have been stationary for 2 seconds.

After recording the 1st point, the other points are taken automatically when the shafts are rotated to a new position and are kept in position for more than 2 seconds.

NOTE: The shafts must be coupled during measurement when using the Multipoint express method.



**Sweep mode method**

9

In the Sweep mode method, the alignment condition can be calculated by recording measurement data automatically while rotating the shafts at least 90° at a moderate speed.

NOTE: The shafts must be coupled during measurement to achieve as reliable and accurate results as possible, when using the Sweep mode method.

TIP: The larger the angle over which the shafts are rotated, the fewer moves, and repeat measurements will have to be made.




**Sweep mode express method**

9

The Sweep mode express method works as the Sweep mode method with the following additions.

After performing the rotation of the shafts and having been stationary for more than a second, the app continues automatically to the result, given that enough measurement data has been collected.




**Clock method**

In the Clock method, machinery positions are calculated by taking three points with 180° of rotation.

The Clock method is useful when comparing the measurement results with traditional alignment methods using dial gauges and reversed rim method. The method can also be used when the machines are standing on non-horizontal foundations or when the shafts are uncoupled.


## MEASUREMENT POINT REGISTRATION




Go to measurement.

Select measurement method.

**Tripoint™ method**




Set the sensors at approximately the same rotational angle at the first measurement position.

Touch the measurement icon, to register the first position.

Rotate the shafts to the next position. The shafts must be rotated over a minimum of 30°.


Red sector shows already measured zone. The Register icon is not shown if the rotation is less than 30°.





Touch the measurement icon, to register the second position.

Rotate the shafts to the third position.






Touch the measurement icon, to register the third position.

TIP: When registering the third position at the 3 o'clock position, the sensors will already be in the right position for horizontal alignment.



**Express Mode™ method**



Set the sensors at approximately the same rotational angle at the first measurement position.




Touch the measurement icon.

This starts the measurement point registration and registers the first position.

The first position can be registered automatically, if the shafts first are rotated counterclockwise more than 3° between 6 o'clock and 12 o'clock and then clockwise more than 3°.

The reading is then taken automatically when the sensors have been stationary for 2 seconds.



Rotate the shafts to the next position. The shafts must be rotated over a minimum of 30°.

Red sector shows already measured zone.

The reading is taken automatically when the sensors have been stationary for 2 seconds.


Rotate the shafts to the third position.

The reading is taken automatically when the sensors have been stationary for 2 seconds.

TIP: When registering the third position at the 3 o’clock position, the sensors will already be in the right position for horizontal alignment.



**Multipoint method**




Set the sensors at approximately the same rotational angle at the first measurement position.



Touch the measurement icon, to register the first position.

Rotate the shafts to the next position. The shafts must be rotated over a minimum of 10°.


Red sector shows already measured zone. The Register icon is not shown if the rotation is less than 10°.





Touch the measurement icon, to register the second position.


Continue to measure. Between 6 and 9 positions can be measured.



Finish measurement.


## Sweep mode method

9



Set the sensors at approximately the same rotational angle at the position where you want to start the sweep measurement.


Touch the measurement icon, to start sweep mode.



A pop-up indicating to rotate the shafts to start the measurement data collection is displayed.

Once the shafts are rotated the data collection will start and an animation will begin showing the optimum speed to rotate the shafts.

Rotate the shafts slowly in one direction (the direction the motor rotates when in use) for ideally 180° or more. A minimum of 90° is required. A slow and steady rotation will increase the amount of data and improve the result.






Finish measurement.

If sufficient measurement data has not been collected, an error message will show up.




The error message shows if the rotation angle was too short or if the shafts were rotated too fast, or both. (In the example above, the rotation angle was too short.)

**Clock method**




Set the sensors at approximately the same rotational angle at the first measurement position, 9 o'clock.








Touch the measurement icon, to register the first position.




Rotate the shafts to the next position, 12 o’clock.








Touch the measurement icon, to register the second position.



Rotate the shafts to the third position, 3 o’clock.








Touch the measurement icon, to register the third position.

**Clock method with disabled inclinometers**

If the inclinometers are not functioning properly, e.g., in high vibrations, they can be disabled.

Go to settings to disable inclinometers.

## MEASUREMENT RESULTS




The Measurement Result screen shows coupling values and foot values in both the vertical and horizontal direction.

The symbol to the left of the coupling values indicates the angular direction and offset, and if the values are within tolerance.



Within tolerance (green).



Within double tolerance (yellow and inverted).



Out of double tolerance (red and inverted).



When a coupling is in tolerance in one direction, this is indicated with a check symbol at the motor.

## EVALUATING AND SAVING THE RESULT

The angle and offset values are used to determine the alignment quality. These values are compared with the alignment tolerances to determine whether correction is necessary. If suitable tolerances are selected in the tolerance table, the symbols described above indicate if the angle and offset values are within tolerance or not.

The foot values indicate the movable machine's foot positions where corrections can be made.

Depending on the result, the program will also guide the user.

First, the program will always guide the user to save the measurement.



Touch the save icon to save the result.

(The measurement is saved in the app and can be handled further by generating a PDF report.)

Then, if the measurement result shows that the machine is misaligned, the user will be guided to go to shimming.

If the measurement result is within tolerance and has been saved, the user will be guided to do a PDF report.

NOTE: It is necessary to make a PDF report for documenting and exporting the measurement from the app.

## VERTIZONTAL™

Align faster with the VertiZontal Moves feature.




First correct the vertical misalignment in the shimming screen. The system shows how much you need to remove or add shims to correct the machine vertically.



Next correct the horizontal misalignment in the alignment screen. The system goes live and will deliver real time values during the adjustment phase.

## SHIMMING




The Shimming screen shows foot values in the vertical direction as suitable shim values (0.05 mm / 1 mil).

The arrows show if shims must be added or removed to adjust the machine in the vertical direction.

The check signs show that shimming is not needed.

When shimming is completed, continue to alignment for adjustments in the horizontal direction.




Go to alignment.

**Shimulator**



Open shimulator.





In the shimulator it is possible to check how different amount of shims affect the result.

## ALIGNMENT

If the machine has been adjusted vertically in the shimming screen, only the horizontal direction remains to align.


If the machine has not been adjusted in the shimming screen, alignment in the vertical direction must be done first.

### Horizontal direction




Rotate the shafts to the 3 or 9 o'clock position, if they are not already positioned there. The angle guide helps you to reach the right position.

Adjust the machine horizontally until the values for both angular and parallel alignment are within tolerance. The arrows by the feet show in which direction the machine should be moved.





Alignment is now completed. To confirm the result, re-do the measurement.



Re-measure.

Tighten the bolts using the tightening sequence, as below.



**Vertical direction**

To check or align in the vertical direction, rotate the shafts to the 12 or 6 o'clock position. The angle guide helps you to reach the right position.

Adjust the machine vertically until the values for both angular and parallel alignment are within tolerance. The arrows by the feet show in which direction the machine should be moved.

**Clock method with disabled inclinometers**

If the inclinometers are not functioning properly, e.g., in high vibrations, they can be disabled.

Go to settings to disable inclinometers.

When the inclinometers are disabled, use the change view icon to change from horizontal to vertical view of the machine and vice versa.



Change view.

## 2-AXIS ALIGNMENT 9

The 2-axis alignment function makes it possible to perform adjustments of the movable machine both in vertical and horizontal direction without further rotations of the shafts.


The 2-axis alignment function is usable when the shaft has limited or no possibility to control the positioning of the shafts during rotation.

Note: This function cannot be used during the following conditions:


- Uncoupled shafts.
- If the shafts rotate during correction.
- If any backlash occurs in the coupling during correction.



Touch the 2-axis alignment icon to go to the 2-axis alignment screen.




The 2-axis alignment screen shows live coupling values and foot values in both the vertical and horizontal direction.



Note: If the sensors are closer to the 12 or 6 o’clock positions backlash can affect the horizontal values and if the sensors are closer to the 3 or 9 o’clock positions backlash can affect the vertical values.

## FEET LOCK FUNCTION


In some cases, the machine that is displayed as the movable machine is not movable, or maybe some of the feet are not adjustable. To perform proper alignment in these cases, the Feet Lock function can be used. This function allows you to select which feet are locked and which feet are adjustable.

Feet Lock is available both in shimming and alignment.




Touch the Feet Lock icon to enter the Feet Lock function.

Enter dimensions. The required distances are those between the first and second pairs of feet on the stationary machine and between the first pair of feet on the stationary machine and the first pair of feet on the movable machine.




Select the two pairs of feet you want to lock.

**Feet Lock Shimming**




Shim values are shown for the two pairs of feet that are not locked.

**Feet Lock Alignment**





Live values are shown for the two pairs of feet that are not locked.

## SCREEN FLIP

Screen Flip enables the user to see the machine set-up from the actual view.



Touch the Screen Flip icon to change view.



## COUPLING GAP


### Configuration




Go to the configuration screen.





Select coupling type.



Activate coupling gap.




Enter coupling diameter.





The coupling diameter can also be entered as circumference.



Enter circumference.

**Measurement results**





The angular error is shown per coupling diameter.

When coupling gap is activated, the coupling diameter is editable in the result screen.

## SPACER SHAFT

The spacer shaft function is used when the alignment is performed on machinery using a membrane coupling. The membrane coupling is a typical high-performance coupling, with no backlash, used for maintenance free operation. It is also suitable for high speeds or high temperature applications.

Membrane couplings are normally designed with a spacer shaft between two flexible elements making it possible to compensate for both axial, radial (offset) and angular misalignment. Each flexible element normally consists of a steel disc pack (diaphragms) which has a high torsional stiffness. A single flexible element can only compensate for angular misalignment and cannot take any radial misalignment. To compensate for all types of misalignments, the membrane couplings use two flexible elements with a spacer in between.




When using the spacer shaft function, the misalignment is presented as an angle for each flexible element. The angles can be compared directly to the figures on allowed misalignment normally delivered from the coupling manufacturer.

Depending upon the alignment condition, there can be differences in angle between the two flexible elements. The pictures below show different examples of how the angles in the flexible elements can be.










**Configuration**



Go to the configuration screen.






Select coupling type.




Activate spacer shaft.

Measure and enter distances.




You must enter all the distances. The distance between the sensors, the “spacer shaft length”, the distance between the “end of the spacer shaft” and the M-sensor, the distance between the M-sensor and the first pair of feet and the distance between the first and the second pair of feet.




**Measurement point registration**

See selected measurement method, the Tripoint method, the Express Mode method or the Clock method.

Generally, the measurement procedure for spacer shaft works in the same way as for standard coupling, except for the two angular values.

**Measurement results**




The Measurement Result screen shows coupling values and foot values in both the vertical and horizontal direction.

The symbol to the left or right of the coupling values indicates the angular direction, and if the values are within tolerance.

**Evaluating and saving the result**

The angle values are used to determine the alignment quality. These values are compared with the alignment tolerance to determine whether correction is necessary. If suitable tolerance is selected in the tolerance table, the symbols described above indicate if the angle values are within tolerance or not.

The foot values indicate the movable machine's foot positions where corrections can be made.



Touch the save icon to save the result.

(The measurement is saved in the app and can be handled further by generating a PDF report.)


**Shimming**

See shimming for standard coupling.

**Alignment**

If the machine has been adjusted vertically in the shimming screen, only the horizontal direction remains to align.

If the machine has not been adjusted in the shimming screen, alignment in the vertical direction must be done first.




Adjust the machine horizontally until both the angular values are within tolerance. The arrows by the feet show in which direction the machine should be moved.

Alignment is now completed. To confirm the result, re-do the measurement.



Re-measure.


## MOTOR COLOR

Motor color can be selected in the configuration screen.

**Motor**




Select motor color.





Select grey, blue, green, yellow, or red.

## SENSOR DISPLAY 9

When using the M9 and S9 sensors a Sensor Display is available in the start screen.



Open Sensor Display.





Raw sensor values (Y, X and rotational angle) are shown, together with an illustration of each sensor where a red dot is showing the laser hit at the detector.

## PDF REPORT

A PDF report with several measurements can be generated.

Touch the PDF icon to create a PDF report.

(The PDF icon is found in the result screen and in the setting screen.)




### Enter data

Touch the white field at the top to enter a header for the PDF report.

Touch the white fields to enter date, site, machine, user and note.

### Select files

Touch the check box to the left to select files.

### Generate and save the PDF report

Touch the save icon to generate and save the PDF report.

Enter a file name and confirm.

The PDF report will then be shown, for further handling. It can be downloaded or shared using standard features of the tablet.

**View a file**

Touch the eye to view a file.

**PDF-report list**




Touch the PDF list icon to view existing PDF-reports.

**IR Pictures**




Touch the IR Picture icon to import IR pictures.

**Customized logo**

Touch the logo up to the right to change it.

Add your logo as a PNG or JPG file. The maximum recommended file size is 500 kB.

The maximum space for logo on the PDF report is 51 x 17 mm.

## OTHER FEATURES

### Looseness indicator



The system has a function for detecting coupling backlash and looseness to achieve optimum accuracy. The system will display the looseness indicator if one of the following conditions is met:

- The M and S units are more than 3° apart.
- The mutual angular position changes more than 0.7° from that when the first measurement point was taken.

When the coupling backlash or looseness is eliminated to avoid any of the above conditions, the looseness indicator will automatically disappear.

### Target Value symbol



When Target Values are used in the measurement, this is indicated with the Target Value symbol in the upper right corner of the screen.

## SETTINGS




### User Log in

Touch the User icon to log in to the ACOEM Augmented Mechanics Platform.

### Info

Touch the Info icon to go to website for downloading user manual.

### Photo

Touch the Photo icon to take a photo.

### Flir One

Touch the IR Photo icon to go to the Flir One app.

### PDF report

Touch the PDF icon to create a PDF report.

### Privacy policy

Touch the Privacy Policy icon to go to website for information about privacy policy.

**Intelligent screen filter and sampling time**



Activate or deactivate intelligent screen filter with increased sampling time.

Note: The intelligent screen filter should be deactivated for normal operation, and only activated in environments with severe vibrations.

**Inclinometer Off**



Deactivate inclinometer.

**2-axis alignment Off** 9



Deactivate 2-axis alignment.

**Measurement unit**



Select mm or inch.

**Best resolution** 9





Select 0.001 mm or 0.01 mils.

**Bluetooth settings**

When entering settings, the system starts searching for pair able sensors.


Only ACOEM sensors that are switched on, will be discovered.




Pair able sensors will appear in the list.



Select the sensors to pair.




Paired units are marked with a check mark.

If there are units paired to the app, they must be unpaired before it is possible to pair new units.



To unpair units, touch the check mark icon beside the units.

**Search**



Starts searching for pairable sensors.

**Cancel search**



Stops searching for pairable sensors.

**Confirm**



Exits the Settings and returns to the application.

## CLOUD SYNCHRONIZATION

Accessing the ACOEM Augmented Mechanics Platform allows for easy collaborative work, sharing machines, results, and providing a centralized multi-technical view (alignment, vibration) for a more effective decision making on maintenance action and plant performance.


### User authentication

To exchange data between the ACOEM Wind - Shaft Alignment app and the cloud, the user must be logged in with a valid login and password. To do so, it is possible to authenticate from the app settings.

Click on the User icon and fill in your login and password that were provided at the creation of your account on the ACOEM Augmented Mechanics Platform (ai.acoem.com).

**NOTE!**

The validity of your information will be checked every time a synchronize action is trigged from the app.






Confirm.



Log out.

**Upload a machine**

Machines that are created in the configuration screen can be uploaded to the cloud.

To do so, from the machine list, display the machine details and touch the upload icon.



Upload to cloud.

**Upload all completed work orders**

From the machine list, touching the cloud synchronization icon will upload all completed and closed work orders.



Cloud synchronization.

**Download available work orders**

From the machine list, touching the cloud synchronization icon will automatically download all work orders assigned to the user logged in to the app.

Machines to be measured with due date will then appear in the machine list.



Cloud synchronization.

**Completing a work order**

Once a job is performed, the work order must be closed by the user prior to the upload to the cloud.

Once the work order is closed, its status is automatically updated in the machine list.

It means that the machine results and report are ready to be uploaded to the cloud and shared with other users.

A work order can either be closed from the result screen or from the machine list, by touching the work order closing icon.



Close the work order.

# HOT CHECK

Hot Check is included in the Wind - Shaft Alignment app.

Hot Check is a simplified way to get Target Values.

The Hot Check is performed by doing a measurement just after the machine has been shut off (hot condition), and another one when the machine has been shut off and cooled down (cold condition). These two measurements are then compared to get Target Values. The measurement result in hot condition is subtracted from the measurement result in cold condition.



**WARNING!**

The machine must be shut off before starting the measurement.

**Measure Hot condition**

Shut off the machine.

Do a Wind - Shaft Alignment measurement, just after the machine has been shut off.

Save this measurement as “…Hot…”.

**Measure Cold condition**

Wait until the machine has cooled down.

Do another Wind - Shaft Alignment measurement.


Save this measurement as “…Cold…”.

**Perform a Hot Check**



Go to Hot Check.

(Hot Check is reached from the configuration screen.)







Pick up a saved measurement in cold condition.

Select the cold measurement to use in the list and confirm.



Pick up a saved measurement in hot condition.


Select the hot measurement to use in the list and confirm.




The screen shows coupling values from the picked-up measurements in cold and hot conditions.



Calculate Target Values.





The screen shows the target values.

7.4

# SENSORS M10 AND S10




Sensors with 1-axis detector, inclinometer and laser transmitter.

1. ON/OFF button with status indication LED
    a. Continuously green – On
    b. Switching green/red – Gyro activated.
2. Mini USB for charging
3. Laser transmission indication LED
    a. Green – laser transmission
4. Bluetooth indication LED
    a. Continuously blue – paired and ready.
    b. Flashing blue – searching/ready to pair
    c. No light – Bluetooth disabled.




5. Battery status button – press to instantly show the battery status (also works when the unit is switched off).

6. Battery status LED
    a. One LED continuously red – less than 10% charge left.
    b. One LED flashing red – less than 5% charge left.
    c. One LED continuously orange – charging
    d. One LED continuously green – fully charged.
7. Battery status LED when battery button is pressed
    a. Continuously green – battery status
    b. Rolling green – battery charging

## OPERATING MODES

Turn the units on and off by pressing the ON/OFF button firmly.

In case the units fail to respond, it is possible to turn it off by pressing down the ON button for more than 10 seconds.

## CONNECTIONS

### Bluetooth connection

The M10 and S10 units are connected by the built in Bluetooth connection. The units will automatically connect to the app when turned on if they are paired. See chapters about apps for instructions on how to pair measurement units.

To avoid accidental Bluetooth transmission in a restricted area the Bluetooth function can be completely disabled – contact your local sales representative for more information.

If the Bluetooth has been disabled (as indicated by the fact that the Bluetooth LED is not flashing or continuously blue when the unit is turned on) it can be enabled by pressing the battery status button quickly 5 times in a row.

## POWER SUPPLY

The M10 and S10 units are powered by a high-capacity rechargeable Li-Ion cell, or by the external power unit.

The operating time of the batteries is approximately 20 hours when the system is used for typical alignment work (continuously on).

The M10 and S10 units can be charged with the supplied charger.

When the external power supply is connected, the unit will automatically start charging the batteries. This will be indicated by the first battery status LED turning orange, when the unit is fully charged the LED will turn green. By pressing the battery status button, the exact charging status can be monitored.

The charging time is approximately 8 hours for fully drained batteries. The charging time will be longer if the unit is turned on while being charged.

When used in typical conditions the batteries will sustain good capacity for approximately 2-3 years before needing replacement. Contact your sales representative for battery replacement.


The batteries contain safety circuitry to operate safely with the unit. The unit can therefore only be used with the Li-Ion batteries supplied by ACOEM. Improper replacement of batteries can cause damage and risk for personal injury. Please refer to the chapter on safety for further instructions.

# SENSORS M9 AND S9




Sensors with 2-axes detector, inclinometer and laser transmitter.

| | |
|---|---|
| 9 | M9 and S9 open additional functions in the apps, marked with Sensor 9 symbol. |




1. Mini USB for charging
2. ON/OFF button with status indication LED
    a. Continuously green – On
    b. Switching green/red – Gyro activated.
3. Laser transmission indication LED
    a. Green – laser transmission

4. Bluetooth indication LED
    a. Continuously blue – paired and ready.
    b. Flashing blue – searching/ready to pair
    c. No light – Bluetooth disabled.
5. Battery status button – press to instantly show the battery status (also works when the unit is switched off).
6. Battery status LED
    a. One LED continuously red – less than 10% charge left.
    b. One LED flashing red – less than 5% charge left.
    c. One LED continuously orange – charging
    d. One LED continuously green – fully charged.
7. Battery status LED when battery button is pressed.
    a. Continuously green – battery status
    b. Rolling green – battery charging
8. Display
    a. Rotational angle.



## OPERATING MODES

Turn the units on and off by pressing the ON/OFF button firmly.

In case the units fail to respond, it is possible to turn it off by pressing down the ON button for more than 10 seconds.

## CONNECTIONS

### Bluetooth connection

The M9 and S9 units are connected by the built in Bluetooth connection. The units will automatically connect to the app when turned on if they are paired. See chapters about apps for instructions on how to pair measurement units.

To avoid accidental Bluetooth transmission in a restricted area the Bluetooth function can be completely disabled – contact your local sales representative for more information.

If the Bluetooth has been disabled (as indicated by the fact that the Bluetooth LED is not flashing or continuously blue when the unit is turned on) it can be enabled by pressing the battery status button quickly 5 times in a row.

## POWER SUPPLY

The M9 and S9 units are powered by a high-capacity rechargeable Li-Ion cell, or by the external power unit.

The operating time of the batteries is approximately 8 hours when the system is used for typical alignment work (continuously on).

The M9 and S9 units can be charged with the supplied charger.

When the external power supply is connected, the unit will automatically start charging the batteries. This will be indicated by the first battery status LED turning orange, when the unit is fully charged the LED will turn green. By pressing the battery status button, the exact charging status can be monitored.

The charging time is approximately 8 hours for fully drained batteries. The charging time will be longer if the unit is turned on while being charged.


When used in typical conditions the batteries will sustain good capacity for approximately 2-3 years before needing replacement. Contact your sales representative for battery re-placement.

The batteries contain safety circuitry to operate safely with the unit. The unit can therefore only be used with the Li-Ion batteries supplied by ACOEM. Improper replacement of batteries can cause damage and risk for personal injury. Please refer to the chapter on safety for further instructions.

## LASER ADJUSTMENT


### Height adjustment





### Side adjustment





## LIGHT HOOD EXTENDABLE

Accessory.







Use in low sun.



Use in high sun.

# ACOEM HOME - LAUNCHER




ACOEM HOME is an easy-to-use launcher.

In ACOEM HOME all available apps are found directly on the home screen. Only run apps approved by ACOEM.

ON/OFF.

Multitasking.

Toggle between apps* and close apps.

Home.

Goes to Home screen.

Return.

Goes to previous screen.

*) NOTE: It is not possible to have several apps using the same sensor open at the same time.

## HOME MENU




In the Home Menu you can select the app that you want to use.

In the Home Menu you will also find access to Settings, File Manager and Info.



Settings



File Manager.




Info.



Off.

## SETTINGS




Brightness.

Auto-Brightness, ON/OFF.


Bluetooth, ON/OFF.

Language.

Date and Time.

## FILE MANAGER

### Content in internal memory of the DU






USB flash drive.


Goes to content on USB flash drive.



Transfer files.

Opens file transfer window.

### Content on USB flash drive






Internal memory.

Goes to content in internal memory.



Transfer files.

Opens file transfer window.

## Transfer files



Select the files to transfer.




Transfer files to USB flash drive.



Transfer files to Display Unit.


## INFO




In Info you will find Quick Guides and Manuals.

It is possible to add and remove PDF files.

## OFF




The OFF screen is just a friendly reminder on how to switch off the Display Unit, to avoid draining the batteries while in storage.

## APP UPDATE

Download the desired app update from the ACOEM Alignment Insite web portal, add it to the USB flash drive and transfer it to the internal memory of the ACOEM DU.

Once transferred (this may take some time) you can press the tab for the internal memory and click on the .apk file to start the installation process.

## ACOEM HOME - FAQ

**Q: Can I use the camera on the ACOEM DU?**
A: Yes, the camera can be accessed from all our apps that support the camera.

**Q: Can I use the FLIR ONE thermal camera on the ACOEM DU?**
A: No, it's not supported.

**Q: Can I turn on Wi-Fi to download material or send email?**
A: No, the Wi-Fi has been disabled and can't be switched on for any use.

**Q: Can I upgrade the apps on the ACOEM Home Screen?**
A: Yes, they can be upgraded. The new app installation files known as .apk files will be made available on the ACOEM Alignment Insite web portal. Download the desired app update and transfer it to the internal memory of the ACOEM DU. Once transferred (this may take some time) you can press the tab for the internal memory and click on the .apk file to start the installation process.


**Q: Can I install 3rd party apps on the ACOEM DU?**
A: No, only a selection of approved apps supplied by ACOEM can be installed.

**Q: Can I use the Acoem DU together with the Bearing Defender or the Machine Defender?**
A: No, the Bearing Defender and the Machine Defender are not supported.


**Q: Can I view or install apk-files directly from the USB stick?**
A: No, files need to be transferred to the internal memory of the ACOEM DU before they can be viewed, accessed, or installed.

**Q: Can I use a new USB C stick?**
A: The USB stick included has been tested and given permission to be accessed by the system. New USB sticks need to be allowed manually at the first use; this also applies for

USB-sticks from other ACOEM systems. See the screenshots below.




Press ‘Use this folder’




Press ‘Allow’

**Q: Can the ACOEM Home be removed from the tablet so I can access all connectivity features?**
A: Yes, the ACOEM Home can be permanently removed. The tablet will then behave and look like a standard Android tablet. This can only be done at ACOEM Sweden at present.

## FLIR ONE 10 9




Thermal imaging camera Flir One Pro-USB-C
External accessory

### SUPPORT

Flir One Pro-USB-C is compatible with the Handheld RT8 - stocked by Acoem AB.

NOTE: Only available on Android.

### APP

Download the Flir One app from Google Play.

Flir One

### INTEGRATION

Possibility to start the Flir One app from inside the Wind - Shaft alignment app.

Touch the IR Photo in Settings icon to go to the Flir One app.

Easily add thermal image to alignment report.

Touch the IR Picture icon in PDF report to import IR pictures.

11.2

# TECHNICAL SPECIFICATION – M10 AND S10

**Art. No. M10 1-1263, S10 1-1264**

| | |
|---|---|
| Housing Material | Anodized Aluminum frame and high impact ABS plastic over molded with TPE rubber |
| Operating Temp | -10 to 50°C (14 to 122°F) |
| Storage Temp | -20 to 70°C (-4 to 158°F) |
| Long term storage temp | Room temp. 18 to 28°C (64 to 82°F) |
| Battery Charging temp | 0 to 40°C (32 to 104°F) |
| Relative humidity | 10 – 90% |
| Weight | M10: 212 g (7,5 oz), S10: 188 g (6,6 oz) |
| Dimensions | 92 mm x 77 mm x 33 mm (3,6 in x 3,0 in x 1,3 in) |
| Environmental protection | IP65 (Dust tight and protected against water jets) |
| Laser | 650 nm class II diode laser |
| Laser line fan angle | 6° |
| Laser line width (1/e2) | 1.6 mm |
| Laser line divergence (full angle) | 0.25 mrad |
| Laser power | < 1 mW |
| Measurement distance | Up to 15 m |
| Detector | 3rd gen. digital sensor |
| Detector length | 30 mm (1,2 in) |

| | |
|---|---|
| Detector angular subtense | 30 mrad/m (3mm/100mm per meter) |
| Detector resolution | 1 µm |
| Measurement accuracy | 0,3% ± 7 µm |
| Signal processing | Digital signal processing with sidespot rejection, edge detection, ambient light elimination and anti-vibration mode |
| Ambient light protection | Optical filtering and digital ambient light signal elimination |
| Inclinometer | Dual High Performance MEMS inclinometers |
| Inclinometer resolution | 0,01° |
| Inclinometer accuracy | ±0,2° |
| Gyroscope | 6-Axis MEMS Inertial Motion Sensor with drift compensation and automatic field calibration |
| Gyroscope accuracy | ±0,5° + 0,5% |
| Wireless communication | BLE Bluetooth Low Energy |
| Communication range | 10 m (33 ft) |
| Connectors | 1 USB Mini port (IP67);<br>Charging: 5V, 0,5A |
| Power supply | High performance Li Ion battery or external power. |
| Operating time | 20 hours continuous use (measuring) |
| Battery Charging time (system off, room temperature) | 8 h |
| Battery Capacity | 11.5 Wh |

| | |
|---|---|
| LED indicators | Unit state, laser transmission and 5 battery status indicators with instant battery check |

Specifications are subject to change without notice.

12.4

# TECHNICAL SPECIFICATION – M9 AND S9

**Art. No. M9 1-1263, S9 1-1264**

| | |
|---|---|
| Housing Material | Anodized Aluminum frame and high impact ABS plastic |
| Operating Temp | -10 to 50°C (14 to 122°F) |
| Storage Temp | -20 to 70°C (-4 to 158°F) |
| Long term storage temp | Room temp. 18 to 28°C (64 to 82°F) |
| Battery Charging temp | 0 to 40°C (32 to 104°F) |
| Relative humidity | 10 – 90% |
| Weight | M9: 306 g (10,8 oz), S9: 306 g (10,8 oz) |
| Dimensions | 100 mm x 77 mm x 43 mm (3,9 in x 3,0 in x 1,7 in) |
| Environmental protection | IP65 (Dust tight and protected against water jets) |
| Laser | 650 nm class II diode laser |
| Laser power | < 1 mW |
| Measurement distance | 63 mm to 20 m |
| Detector | 2-axis PSD |
| Detector size | 20 mm x 20 mm (0,79 in x 0,79 in) |
| Detector resolution | 1 µm |
| Measurement accuracy | 1% ± 3 µm |

| | |
|---|---|
| Ambient light protection | Optical filtering and digital ambient light signal elimination |
| Inclinometer | Dual High Performance MEMS inclinometers |
| Inclinometer resolution | 0,01° |
| Inclinometer accuracy | ±0,1° |
| Gyroscope | 6-Axis MEMS Inertial Motion Sensor with drift compensation and automatic field calibration |
| Gyroscope accuracy | ±0,5° + 0,5% |
| Wireless communication | BLE Low Energy Bluetooth |
| Communication range | 10 m (33 ft) |
| Connectors | 1 USB Mini port (IP67);<br>Charging: 5V, 0,5A |
| Power supply | High performance Li Ion battery or external power. |
| Operating time | 8 hours continuous use (measuring) |
| Battery Charging time (system off, room temperature) | 8 h |
| Battery Capacity | 11.5 Wh |
| LED indicators | Unit state, laser transmission and 5 battery status indicators with instant battery check |

Specifications are subject to change without notice.



acoem

CREATING ENVIRONMENTS OF POSSIBILITY

Publication No. P-0372-GB

© 2025 ACOEM AB, Mölndal, Sweden
All rights reserved. No part of this manual may be copied or reproduced in any form or by any means without prior permission from ACOEM AB

acoem.com